

Znacka	FERODO
Cislo výrobku	FDB114
Oznaceni	Sada brzdových destiček, kotoučová brzda
Dodatečne oznaceni.	PREMIER
EAN	50 16687 00897 5
Jednotka baleni	1
Mnozstvi pro balici jednotku	4
Pouzite cislo	20336
Pouzite cislo	20337


verwendet in Fahrzeugen

Bezeichnung	Baujahr	KW	PS	Ccm	Bauart	Konfig.	To.
ALPIN 1300 1.3	01.74 - 12.75	54	73	1289	kupé		
ALPIN 1300 1.3 85	01.70 - 12.73	60	81	1289	kupé		
ALPIN 1300 1.3 G	01.70 - 12.72	76	103	1255	kupé		
ALPIN 1300 1.3 S	01.70 - 12.72	97	132	1296	kupé		
ALPIN 1600 1.6	01.70 - 12.71	75	102	1565	kupé		
ALPIN 1600 1.6 S	01.69 - 12.73	101	138	1565	kupé		
ALPIN 1600 1.6 SC-SI	01.73 - 12.75	93	127	1605	kupé		
ALPIN 1600 1.6 SC-SI	01.73 - 12.75	103	140	1605	kupé		
ALPIN A310 1.6	01.71 - 12.77	93	127	1605	kupé		
ALPIN A310 1.6 Injection	01.76 - 12.77	94	127	1605	kupé		
ALPIN A310 1.7	01.71 - 12.77	70	95	1647	kupé		
ALPIN A310 2.7 V6	01.76 - 12.84	110	150	2664	kupé		
ALPIN BERLINETTE 1300	01.76 - 12.77	50	68	1289	kupé		
ALPIN BERLINETTE 1600 SX	01.76 - 12.77	70	95	1647	kupé		
DACIA SOLENZA 1.4	02.03	55	75	1390	Sikma zadni cast		
DACIA SOLENZA 1.9 D	02.03	46	63	1870	Sikma zadni cast		
FIAT 130 2.9	10.70 - 12.71	117	160	2866	limuzína		
FIAT 130 2.9	06.69 - 12.71	103	140	2866	limuzína		
FIAT 130 3.2 (B)	12.71 - 03.78	121	165	3235	limuzína		
FIAT 130 kupé 3.2 (BC)	10.71 - 03.78	121	165	3235	kupé		
LOTUS ESPRIT S4 (082) 2.2 16V Turbo SE	05.89 - 09.96	197	268	2174	kupé		

verwendet in Fahrzeugen

Bezeichnung	Baujahr	KW	PS	Ccm	Bauart	Konfig.	To.
LOTUS ESPRIT S4 (082) 3.5 V8 32V Turbo	02.96 - 06.03	260	354	3506	kupé		
LOTUS EXCEL 2.2 SE/SA	10.84 - 08.91	135	184	2172	kupé		
RENAU 12 1.6 Gordini (1173)	08.70 - 12.74	83	113	1565	limuzína		
RENAU 15 (130_) 1.6 (1302)	03.72 - 10.80	66	90	1565	Sikma zadni cast		
RENAU 17 1.6	03.72 - 10.80	66	90	1565	kupé		
RENAU 17 1.6 Gordini	03.74 - 10.80	79	108	1605	kupé		
RENAU 18 (134_) 1.6 Turbo (1345)	10.82 - 07.86	92	125	1565	limuzína		
RENAU 18 (134_) 1.6 Turbo (1345)	10.80 - 09.82	80	109	1565	limuzína		
RENAU 18 Variable (135_) 1.6 Turbo	10.82 - 07.86	92	125	1565	kombík		
RENAU 21 (B48_) 2.0 (B48R/Y)	02.90 - 10.92	99	135	1995	Sikma zadni cast		
RENAU 21 (B48_) 2.0 4x4 (B48R/Y)	09.90 - 10.92	99	135	1995	Sikma zadni cast		
RENAU 21 (B48_) 2.1 D (B480)	04.92 - 06.94	51	69	2068	Sikma zadni cast		
RENAU 21 (B48_) 2.1 D (B48V/B48O)	09.89 - 12.92	53	72	2068	Sikma zadni cast		
RENAU 21 (B48_) 2.1 Turbo-D (B486, B488, B48V)	09.89 - 06.94	65	88	2068	Sikma zadni cast		
RENAU 21 (B48_) 2.2 (B48K)	09.89 - 06.94	79	107	2165	Sikma zadni cast		
RENAU 21 (B48_) 2.2 4x4 (B48K)	07.90 - 06.94	79	107	2165	Sikma zadni cast		
RENAU 21 kombík (K48_) 2.0 (K483)	06.86 - 12.88	85	116	1995	kombík		
RENAU 21 kombík (K48_) 2.0 (K48R)	06.90 - 02.94	99	135	1995	kombík		
RENAU 21 kombík (K48_) 2.1 D (K/S486)	10.86 - 09.90	48	65	2068	kombík		
RENAU 21 kombík (K48_) 2.1 D (K/S48V, K/S48O)	08.89 - 12.92	53	72	2068	kombík		
RENAU 21 kombík (K48_) 2.1 D (K480)	02.92 - 09.95	51	69	2068	kombík		
RENAU 21 kombík (K48_) 2.1 D 4x4 (K486)	10.88 - 05.92	48	65	2068	kombík		
RENAU 21 kombík (K48_) 2.1 Turbo-D (K48A, K48W, K487, K488)	10.86 - 11.93	65	88	2068	kombík		
RENAU 21 kombík (K48_) 2.2 (K48K)	06.86 - 11.93	79	108	2165	kombík		
RENAU 21 kombík (K48_) 2.2 4x4 (K48K)	06.86 - 12.93	79	107	2165	kombík		
RENAU 21 limuzína (L48_) 2.0	05.91 - 10.93	78	106	1995	limuzína		
RENAU 21 limuzína (L48_) 2.0	04.86 - 06.89	86	117	1995	limuzína		
RENAU 21 limuzína (L48_) 2.0 (L483)	03.86 - 12.88	85	116	1995	limuzína		
RENAU 21 limuzína (L48_) 2.0 (L48R)	02.90 - 06.94	99	135	1995	limuzína		
RENAU 21 limuzína (L48_) 2.0 4x4 (L48R)	12.89 - 02.94	99	135	1995	limuzína		
RENAU 21 limuzína (L48_) 2.0 Turbo (L485)	04.87 - 03.90	129	175	1995	limuzína		
RENAU 21 limuzína (L48_) 2.0 Turbo 4x4	08.89 - 10.93	129	175	1995	limuzína		
RENAU 21 limuzína (L48_) 2.0 Turbo 4x4 (L48L)	02.90 - 10.92	119	162	1995	limuzína		
RENAU 21 limuzína (L48_) 2.1 D (L480)	10.92 - 06.94	51	69	2068	limuzína		

verwendet in Fahrzeugen

Bezeichnung	Baujahr	KW	PS	Ccm	Bauart	Konfig.	To.
RENAU 21 limuzína (L48_) 2.1 D (L486)	03.86 - 12.89	48	65	2068	limuzína		
RENAU 21 limuzína (L48_) 2.1 D (L48V, L48O)	05.89 - 06.94	53	72	2068	limuzína		
RENAU 21 limuzína (L48_) 2.1 Turbo-D (L48A, L48W, L487, L488)	03.86 - 06.94	65	88	2068	limuzína		
RENAU 21 limuzína (L48_) 2.2 (L48K)	07.86 - 02.94	79	107	2165	limuzína		
RENAU 21 limuzína (L48_) 2.2 4x4 (L48K)	07.90 - 02.94	79	107	2165	limuzína		
RENAU 25 (B29_) 2.0 (B297)	04.84 - 12.92	74	101	1995	Sikma zadni cast		
RENAU 25 (B29_) 2.0 12V	06.88 - 12.93	103	140	1995	Sikma zadni cast		
RENAU 25 (B29_) 2.0 12V (B294)	06.89 - 12.92	99	135	1995	Sikma zadni cast		
RENAU 25 (B29_) 2.1 Diesel (B296)	06.89 - 12.92	51	69	2068	Sikma zadni cast		
RENAU 25 (B29_) 2.1 Diesel (B296)	04.84 - 05.89	46	63	2068	Sikma zadni cast		
RENAU 25 (B29_) 2.1 Turbo-D (B290, B29W)	04.84 - 12.92	63	86	2068	Sikma zadni cast		
RENAU 25 (B29_) 2.2 (B29)	11.85 - 03.89	76	103	2165	Sikma zadni cast		
RENAU 25 (B29_) 2.2 (B29B)	09.86 - 12.92	79	108	2165	Sikma zadni cast		
RENAU 25 (B29_) 2.2 (B29E)	04.84 - 12.89	91	124	2165	Sikma zadni cast		
RENAU 25 (B29_) 2.2 (B29E)	04.84 - 12.89	89	121	2165	Sikma zadni cast		
RENAU 25 (B29_) 2.4 V6 Turbo (B295)	10.84 - 05.90	133	181	2458	Sikma zadni cast		
RENAU 25 (B29_) 2.5 V6 Turbo (B29G)	01.90 - 12.92	151	205	2458	Sikma zadni cast		
RENAU 25 (B29_) 2.7 V6 Injection (B298)	04.84 - 08.89	104	141	2664	Sikma zadni cast		
RENAU 25 (B29_) 2.8 V6 (B293)	06.87 - 02.90	115	156	2849	Sikma zadni cast		
RENAU 25 (B29_) 2.8 V6 Injection (B29A)	06.86 - 02.88	100	136	2849	Sikma zadni cast		
RENAU 25 (B29_) 2.8 V6 Injection (B29F)	06.87 - 12.92	110	150	2849	Sikma zadni cast		
RENAU 30 (127_) 2.6 (1273)	08.76 - 08.78	92	125	2664	Sikma zadni cast		
RENAU 30 (127_) 2.6 (1273)	02.75 - 07.76	96	131	2664	Sikma zadni cast		
RENAU 30 (127_) 2.6 TS (1275)	07.78 - 01.84	94	128	2664	Sikma zadni cast		
RENAU 30 (127_) 2.6 TX (1278)	10.78 - 12.83	105	143	2664	Sikma zadni cast		
RENAU 5 (122_) 1.4 Alpine A5 (1223)	09.77 - 09.81	68	93	1397	Sikma zadni cast		
RENAU 5 (122_) 1.4 Alpine Turbo (122B)	10.81 - 01.85	79	108	1397	Sikma zadni cast		
RENAU 5 (122_) 1.4 Turbo (8220)	06.80 - 01.85	118	160	1397	Sikma zadni cast		
RENAU ESPACE I (J11_) 2.0 (J/S112)	01.88 - 12.90	74	101	1995	velkoprostorová limuzína		
RENAU ESPACE I (J11_) 2.0 (J/S112)	07.84 - 12.90	80	109	1995	velkoprostorová limuzína		
RENAU ESPACE I (J11_) 2.0 i (J116)	01.89 - 12.90	87	118	1995	velkoprostorová limuzína		
RENAU ESPACE I (J11_) 2.0 i Quadra (J116)	03.88 - 12.92	87	118	1995	velkoprostorová limuzína		

verwendet in Fahrzeugen

Bezeichnung	Baujahr	KW	PS	Ccm	Bauart	Konfig.	To.
RENAU ESPACE I (J11_) 2.1 TD (J/S115)	10.84 - 12.90	65	88	2068	velkoprostorová limuzína		
RENAU ESPACE I (J11_) 2.2 (J117)	07.86 - 12.90	79	108	2165	velkoprostorová limuzína		
RENAU ESPACE I (J11_) 2.2 Quadra (J117)	01.88 - 12.90	79	108	2165	velkoprostorová limuzína		
RENAU ESPACE II (J/S63_) 2.0 (J636)	01.91 - 10.96	76	103	1995	velkoprostorová limuzína		
RENAU ESPACE II (J/S63_) 2.1 TD (J633, J634, J/S635, J/S63D)	01.91 - 10.96	65	88	2068	velkoprostorová limuzína		
RENAU ESPACE II (J/S63_) 2.1 TD (J63E)	11.94 - 10.96	66	90	2068	velkoprostorová limuzína		
RENAU ESPACE II (J/S63_) 2.2 (J/S637, J63G)	01.91 - 10.96	79	108	2165	velkoprostorová limuzína		
RENAU ESPACE II (J/S63_) 2.2 4x4 (J/S637, J63G)	03.91 - 12.96	79	108	2165	velkoprostorová limuzína		
RENAU ESPACE II (J/S63_) 2.8 V6 (J638, J63J)	01.91 - 10.96	110	150	2849	velkoprostorová limuzína		
RENAU FUEGO (136_) 1.6 Turbo (1365)	08.83 - 10.85	97	132	1565	kupé		
TALBO MATRA BAGHEERA (X) 1.3 (X3550)	01.74 - 03.78	62	84	1294	kupé		
TALBO MATRA BAGHEERA (X) 1.4 (X6)	11.79 - 09.80	66	90	1442	kupé		
TALBO MATRA BAGHEERA (X) 1.4 (X6)	11.79 - 09.80	62	84	1442	kupé		
TALBO MATRA BAGHEERA (X) 1.4 (X6550)	12.75 - 11.79	66	90	1442	kupé		
TALBO MURENA 1.6	08.81 - 01.85	66	90	1577	kupé		
TALBO MURENA 2.1	09.80 - 07.84	85	116	2156	kupé		
TALBO MURENA 2.1 S	04.83 - 01.85	103	140	2128	kupé		

